

RTCA, Inc.
1150 18th Street, NW, Suite 910
Washington D.C. 20036

User Guide

Supplement to DO-160G

FOREWORD

This document was prepared by Special Committee 135 (SC-135) and was approved by the RTCA Program Management Committee (PMC) on December 16, 2014.

RTCA, Incorporated is a not-for-profit corporation formed to advance the art and science of aviation and aviation electronic systems for the benefit of the public. The organization functions as a Federal Advisory Committee and develops consensus-based recommendations on contemporary aviation issues. RTCA's objectives include but are not limited to:

- coalescing aviation system user and provider technical requirements in a manner that helps government and industry meet their mutual objectives and responsibilities;
- analyzing and recommending solutions to the system technical issues that aviation faces as it continues to pursue increased safety, system capacity and efficiency;
- developing consensus on the application of pertinent technology to fulfill user and provider requirements, including development of minimum operational performance standards for electronic systems and equipment that support aviation; and
- assisting in developing the appropriate technical material upon which positions for the International Civil Aviation Organization and the International Telecommunications Union and other appropriate international organizations can be based.

The organization's recommendations are often used as the basis for government and private sector decisions as well as the foundation for many Federal Aviation Administration Technical Standard Orders.

Since RTCA is not an official agency of the United States Government, its recommendations may not be regarded as statements of official government policy unless so enunciated by the U.S. government organization or agency having statutory jurisdiction over any matters to which the recommendations relate.

TABLE OF CONTENTS

Purpose and Applicability.....	1
User Guide for Section 4 - Temperature & Altitude.....	3
User Guide for Section 5 - Temperature Variation.....	13
User Guide for Section 7 - Operational Shocks and Crash Safety.....	21
User Guide for Section 8 - Vibration.....	29
User Guide for Section 9 - Explosion Proofness.....	45
User Guide for Section 10 - Waterproofness.....	53
User Guide for Section 11 - Fluids Susceptibility.....	59
User Guide for Section 15 - Magnetic Effect.....	65
User Guide for Section 16 - Power Input.....	75
User Guide for Section 17 - Voltage Spike.....	87
User Guide for Section 18 - Audio Frequency Conducted Susceptibility – Power Inputs.....	95
User Guide for Section 20 - Radio Frequency Susceptibility.....	103
User Guide for Section 21 - Emission of Radio Frequency Energy.....	153
User Guide for Section 22 - Lightning Induced Transient Susceptibility.....	163
User Guide for Section 23 - Lightning Direct Effects.....	193
User Guide for Section 26 – Fire, Flammability.....	225
Appendix A Membership.....	241

Purpose and Applicability

The purpose of this document is to provide users of DO-160G additional background information for the associated test procedures and requirements in DO-160G. This information includes rationale for requirements, guidance in applying the requirements, commentary, possible trouble shooting techniques, and lessons learned from laboratory experience. This User Guide is provided for guidance purposes and does not contain requirements. This information is intended to help users understand the objective and rationale behind the requirements, and to help users develop detailed test procedures based on the general test procedures in this document. It is highly recommended that detailed discussion will take place between the equipment manufacturer and the equipment installer during the development of the test plan.

Note that the User Guide subsections are numbered independently of the subsections in DO-160G.

DO-357 replaces the User Guides previously included in DO-160G.

DO-160G Change 1 has been published to remove all User Guides previously included in DO-160G.

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 4

Temperature & Altitude

**Based on
DO-160G Section 4**

TABLE OF CONTENTS

4.UG.0	Temperature and Altitude	7
4.UG.1	Purpose of the Tests	7
4.UG.2	General	7
4.UG.3	Equipment Categories	7
4.UG.4	Definitions of Terms	7
4.UG.5	Temperature Tests.....	7
4.UG.5.1	Ground Survival Low Temperature Test and Short-Time Operating Low Temperature Test	7
4.UG.5.2	Operating Low Temperature Test	9
4.UG.5.3	Ground Survival High Temperature Test and Short-Time Operating High Temperature Test.....	9
4.UG.5.4	Operating High Temperature Test.....	10
4.UG.5.5	In-Flight Loss of Cooling Test	10
4.UG.6	Altitude, Decompression and Overpressure Tests.....	11
4.UG.6.1	Altitude Test.....	11
4.UG.6.2	Decompressions Test.....	11
4.UG.6.3	Overpressure Test.....	11

TABLE OF FIGURES

Figure 4.UG-1	- Combined Ground Survival Low Temp and Operating Low Temp Test.....	8
Figure 4.UG-2	- Combined Ground Survival High Temp and Operating High Temp Test.....	9

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 5

Temperature Variation

**Based on
DO-160G Section 5**

TABLE OF CONTENTS

5.UG.0	Temperature Variation	17
5.UG.1	Purpose of the Test.....	17
5.UG.2	Temperature Change Rates	17
5.UG.3	Test Procedure.....	17
5.UG.3.1	Test Procedure Categories A, B, and C.....	17
5.UG.3.2	Test Procedure Category S1.....	19
5.UG.3.3	Test Procedure Category S2.....	19

TABLE OF FIGURES

Figure 5.UG-1	- Temp Variation without Short Time Operating conditions.....	18
Figure 5.UG-2	- Temp Variation with Short Time Operating conditions.....	19

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 7

Operational Shocks and Crash Safety

**Based on
DO-160G Section 7**

TABLE OF CONTENTS

7.UG.0	Operational Shocks and Crash Safety	25
7.UG.1	Purpose of the Tests	25
7.UG.2	Equipment Categories	26
7.UG.3	Operational Shocks	26
7.UG.3.1	Test Procedure.....	26
7.UG.3.2	Alternate Test Procedure.....	27
7.UG.4	Crash Safety	27
7.UG.4.1	Test Procedure 1 (Impulse)	27
7.UG.4.2	Alternate Test Procedure (Impulse)	27
7.UG.4.3	Test Procedure 2 (Sustained).....	27

TABLE OF TABLES

Table 7.UG-1 - Comparison of velocity and displacement changes during shock.....	25
--	----

TABLE OF FIGURES

Figure 7.UG-1 - Shock Response Spectra for the 6 g shock impulses.....	27
--	----

DO-160G

**Environmental Conditions and Test
Procedures for Airborne Equipment**

User Guide for Section 8

Vibration

**Based on
DO-160G Section 8**

TABLE OF CONTENTS

8.UG.0	Vibration.....	33
8.UG.1	Purpose of the Tests	33
8.UG.2	Applicability.....	33
8.UG.3	Vibration Test Category Definitions	34
8.UG.3.1	Standard Vibration Test (Category S).....	34
8.UG.3.2	Robust Vibration Test (Categories R, U, U2).....	34
8.UG.3.3	High-Level, Short Duration Vibration Test (Categories H, Z)	34
8.UG.4	Test Curve / Test Level Selection	35
8.UG.4.1	Test Description	35
8.UG.4.2	Test Curves.....	35
8.UG.5	Vibration Test Requirements.....	36
8.UG.6	Vibration Test Level Requirements.....	41
8.UG.6.1	Control Level Tolerance Requirements	41
8.UG.6.1.1	Sinusoidal Control Input	41
8.UG.6.1.2	Random Control Input.....	41
8.UG.6.2	Measurement of Acceleration Power Spectral Density	42
8.UG.6.2.1	Analog Analyzer Requirements	42
8.UG.6.2.2	Digital Analyzer Requirements	42
8.UG.7	Standard Vibration Test Procedure-Fixed Wing Aircraft	42
8.UG.7.1	Sinusoidal Test Procedure	42
8.UG.7.2	Random Test Procedure.....	42
8.UG.8	High-Level, Short Duration Vibration Test Procedure	42
8.UG.9	Robust Vibration Test Procedure-Fixed-Wing Aircraft.....	42
8.UG.9.1	Sinusoidal Test Procedure	42
8.UG.9.2	Random Test Procedure.....	42
8.UG.10	Vibration Test for Helicopters.....	42
8.UG.10.1	Sine-on-Random Test Procedure – Known Helicopter Frequencies	42
8.UG.10.1.1	Test Frequencies.....	42
8.UG.10.1.2	Sine and Random Test Levels.....	43
8.UG.10.1.3	Procedure	43
8.UG.10.2	Sine-on-Random Test Procedure for Category U – Unknown Helicopter Frequencies	43
8.UG.10.3	Random Test Procedure for Category U2 – Unknown Helicopter Frequencies.....	43

TABLE OF TABLES

Table 8.UG-1 - Reduction Factors for Heavy Equipment	36
Table 8.UG-2 - Summary of Vibration EQF reporting requirements	40
Table 8.UG-3 - Example EQF Reporting of Critical and/or Resonant Frequency Changes.....	41

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 9

Explosive Atmosphere

**Based on
DO-160G Section 9**

TABLE OF CONTENTS

9.UG.0	Explosive Atmosphere	49
9.UG.1	Purpose of the Test	49
9.UG.2	Explosion Proof.....	49
9.UG.3	Equipment Categories	49
9.UG.3.1	Category A Equipment.....	49
9.UG.3.2	Category E Equipment	49
9.UG.3.3	Category H Equipment.....	49
9.UG.4	General Test Requirements	49
9.UG.4.1	General	49
9.UG.4.2	Test Specimen	49
9.UG.4.3	Fuel.....	49
9.UG.4.4	Fuel Mixture.....	49
9.UG.5	Equipment Design and Installation Information	50
9.UG.6	Test Procedures	50
9.UG.6.1	Containment Test	50
9.UG.6.2	Non Ignition Test	51
9.UG.6.3	Components of Surface Temperature Test.....	51

DO-160G

**Environmental Conditions and Test
Procedures for Airborne Equipment**

User Guide for Section 10

Waterproofness

**Based on
DO-160G Section 10**

TABLE OF CONTENTS

10.UG.0	Waterproofness	57
10.UG.1	Purpose of the Test.....	57
10.UG.2	Equipment Categories	57
10.UG.3	Test Procedures	57
10.UG.3.1	Condensing Water Proof Test	57
10.UG.3.2	Drip Proof Test.....	57
10.UG.3.3	Spray Proof Test.....	57
10.UG.3.4	Continuous Stream Proof Test	57

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 11

Fluids Susceptibility

**Based on
DO-160G Section 11**

TABLE OF CONTENTS

11.UG.0	Fluids Susceptibility	63
11.UG.1	Purpose of the Test	63
11.UG.2	Precautions.....	63
11.UG.3	Equipment Categories.....	63
11.UG.4	Test Procedures.....	63
11.UG.4.1	Spray Test.....	63
11.UG.4.2	Immersion Test.....	63
11.UG.5	Use of Material Specimens.....	63

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 15

Magnetic Effect

**Based on
DO-160G Section 15**

TABLE OF CONTENTS

15.UG.0 Magnetic Effect	69
15.UG.1 Purpose of the Test.....	69
15.UG.2 Test Description	69
15.UG.3 Test Procedure.....	70

TABLE OF FIGURES

Figure 15.UG-1 - Helmholtz coils.....	72
---------------------------------------	----

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 16

Power Input

**Based on
DO-160G Section 16**

TABLE OF CONTENTS

16.UG.0	Introduction.....	79
16.UG.1	Voltage distortion.....	79
16.UG.2	Momentary Power Interruptions (DC).....	80
16.UG.3	Abnormal Surge Voltage (AC and DC).....	81
16.UG.4	Current Harmonics.....	81
16.UG.5	Current Distortion.....	81
16.UG.6	DC Current Content in Steady-State Operation (All AC Equipment).....	81
16.UG.7	Inrush Current.....	82
16.UG.8	Current Modulation test in steady state operation.....	82
16.UG.9	Power Factor.....	84

TABLE OF TABLES

Table 16.UG-1	- Multiple Equipment Level Testing Table.....	85
---------------	---	----

TABLE OF FIGURES

Figure 16.UG-1	Top - Extracted Modulated Current, Bottom - Equipment Steady State Current.....	83
----------------	---	----

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 17

Voltage Spike

**Based on
DO-160G Section 17**

TABLE OF CONTENTS

17.UG.0 Voltage Spike	91
17.UG.1 Purpose of the test	91
17.UG.2 Equipment Categories	91
17.UG.3 Test Setup and Apparatus.....	91
17.UG.4 Test Procedure.....	91

TABLE OF FIGURES

Figure 17.UG-1 - Measured Voltage Spike Calibration.....	92
Figure 17.UG-2 - Voltage Spike Test Setup, DC or single phase AC.....	93

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 18

Audio Frequency Conducted Susceptibility – Power Inputs

**Based on
DO-160G Section 18**

TABLE OF CONTENTS

18.UG.0	Audio Frequency Conducted Susceptibility - Power Inputs.....	99
18.UG.1	Purpose of the Test.....	99
18.UG.2	Equipment Categories and Frequency Classes.....	99
18.UG.3	Equipment Categories	99
18.UG.4	Test Procedures	99
18.UG.5	DC Input Power Leads	100
18.UG.6	AC Input Power Leads	100
18.UG.7	Frequency Scan Rates	100
18.UG.8	General Remarks.....	100

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 20

Radio Frequency Susceptibility (Radiated and Conducted)

**Based on
DO-160G Section 20**

TABLE OF CONTENTS

20.UG.0	Radio Frequency Susceptibility (Radiated and Conducted)	107
20.UG.1	Purpose of the Test.....	107
20.UG.2	Equipment Categories	107
20.UG.3	General Test Requirements.....	111
20.UG.4	Conducted Susceptibility (CS) Test.....	122
20.UG.5	Radiated Susceptibility (RS) Test - Anechoic Chamber Method	136
20.UG.6	Radiated Susceptibility (RS) Test; Reverberation Chamber - Method	143
20.UG.6.1	Applicability/Intent.....	143
20.UG.6.2	Procedure Overview	143
20.UG.6.3	Calibration, Chamber Field Uniformity and Loading Validation.....	150
20.UG.6.3.1	Field Uniformity Validation.....	150
20.UG.6.3.2	Chamber Time Constant Calculation	150

TABLE OF TABLES

Table 20.UG-1 - Category Definition for the Conducted Susceptibility Test in Terms of Aircraft Type and HIRF Environment	110
Table 20.UG-2 - Category Definition for the Radiated Susceptibility Test in Terms of Location on the Aircraft and the HIRF Environment	111
Table 20.UG-3 - Test Frequencies for 1 Decade	121
Table 20.UG-4 - Wire Bundling/Testing	128

TABLE OF FIGURES

Figure 20.UG-1 - LISN Input Impedance.....	113
Figure 20.UG-2 - Representative Schematic Diagram for the Line Impedance Stabilizing Network	114
Figure 20.UG-3 - CS Test Problem Caused by Pigtail or Ground Wire.....	115
Figure 20.UG-4 - Pulse Modulated or Gated Signal.....	117
Figure 20.UG-5 - Amplitude modulated waveform	117
Figure 20.UG-6 - Pulsed Susceptibility Forward Power Measurement, Ringing on Leading Edge	119
Figure 20.UG-7 - Pulsed Susceptibility Forward Power, Ringing on Leading Edge Test Setup	119
Figure 20.UG-8 - Pulsed Susceptibility forward Power, Improved Test Setup.....	120
Figure 20.UG-9 - Pulsed Susceptibility Forward Power Measurement, Improved Waveform	120
Figure 20.UG-10 - Single Injections Required	123
Figure 20.UG-11 - Multiple Injection Points With Dual Channel Injection	124
Figure 20.UG-12 - Bulk Current Injection Calibration Set-Up	125
Figure 20.UG-13 - Specified Insertion Loss of the Injection Probes.....	126
Figure 20.UG-14 - Bulk Current Injection Test - Recommended Calibration Jig Design (ref. MIL-STD-461E)	127

Figure 20.UG-15 - Calibration Jig Maximum VSWR Limit.....	127
Figure 20.UG-16 - Wiring Inclusion within Current Probe.....	129
Figure 20.UG-17 - Verification Setup for Conducted Susceptibility Test Section 20.4.....	130
Figure 20.UG-18 - Bulk Current Injection Test - Loop Impedance Measurement.....	132
Figure 20.UG-19 - Variation in Coupling by Injection Probe Movement on a Single Wire.....	133
Figure 20.UG-20 - Variation in Coupling by Injection Probe Movement on a System Harness	134
Figure 20.UG-21 - Variation in Coupling by Monitor Probe Movement on a Single Wire	134
Figure 20.UG-22 - Variation in Coupling by Monitor Probe Movement on a System Harness.....	135
Figure 20.UG-23 - Field Calibration Test Arrangement	137
Figure 20.UG-24 - Antenna Beam Width Diagram.....	138
Figure 20.UG-25 - Cables Routed in Same Direction	139
Figure 20.UG-26 - Cables Routed in Opposite Directions	140
Figure 20.UG-27 - Radiated Susceptibility Test - VSWR of the Biconical Antenna in a Shielded Room - No Anechoic Absorber in Close Proximity Around Transmitter.....	141
Figure 20.UG-28 - Radiated Susceptibility Test - VSWR of the Biconical Antenna in a Shielded Room - With Anechoic absorber in close proximity around transmitter	141
Figure 20.UG-29 - Side View of a Typical Reverberation Chamber	144
Figure 20.UG-30 - Histogram Showing an Example of the Ratio of Peak to Average Values of Field Strength.....	145
Figure 20.UG-31 - Field Variation with Respect to Tuner Rotation	148
Figure 20.UG-32 - Forward Power Repeatability, 3 Independent Runs, One Antenna Position	149
Figure 20.UG-33 - Moving Average Technique on Measured Forward Power Data for 100 V/m Field Strength.....	150

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 21

Emission of Radio Frequency Energy

**Based on
DO-160G Section 21**

TABLE OF CONTENTS

21.UG.0	Emission of Radio Frequency Energy	157
21.UG.1	Purpose of the User Guide	157
21.UG.2	Equipment Categories	157
21.UG.3	General Requirements	158
21.UG.4	Conducted RF Emissions	159
21.UG.5	Radiated RF Emission	160
21.UG.6	Radiated RF Emissions; Reverberation Chamber Procedure	162
21.UG.6.1	Reverberation Chamber Requirements	162
21.UG.6.2	Reverberation Chamber Insertion Loss	162
21.UG.6.3	Radiated RF Emissions Test	162

TABLE OF FIGURES

Figure 21.UG-1	- Problem caused by pigtail or grounding wire	160
----------------	---	-----

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 22

Lightning Inducted Transient Susceptibility

**Based on
DO-160G Section 22**

TABLE OF CONTENTS

22.UG.0	Lightning Induced Transient Susceptibility.....	167
22.UG.1	Purpose of the Test.....	167
22.UG.2	Definitions.....	167
22.UG.3	Categories.....	167
22.UG.4	General Test Requirements.....	168
22.UG.5	Test Procedures.....	175
22.UG.5.1	Pin Injection Test.....	175
22.UG.5.1.1	Procedures - Generator Calibration.....	181
22.UG.5.1.2	Procedures - Test Sequence.....	182
22.UG.5.2	Cable Bundle Tests.....	182
22.UG.5.2.1	Cable Induction Test.....	185
22.U.5.2.1.1	Procedures - Generator Performance Verification.....	185
22.UG.5.2.1.2	Procedures - Test Sequence.....	185
22.UG.5.2.2	Ground Injection Tests.....	192
22.UG.5.2.2.1	Procedures - Generator Performance Verification.....	192
22.UG.5.2.2.2	Procedures - Test Sequence.....	192

TABLE OF TABLES

Table 22.UG-1: Remote Load TVS.....	169
-------------------------------------	-----

TABLE OF FIGURES

Figure 22.UG-1 - Interface Loads and Support Equipment.....	169
Figure 22.UG-2 - Combined Double-Exponential and Oscillatory Waveform.....	175
Figure 22.UG-3 - Simplified Discrete Output Interface.....	177
Figure 22.UG-4 - Transient Applied on an Opened-State Circuit.....	177
Figure 22.UG-5 - Lightning Transient Applied to a Closed-State Circuit.....	178
Figure 22.UG-6 - Multiple Pins Protected by a Single Device.....	180
Figure 22.UG-7 - Waveform Test Process.....	184
Figure 22.UG-8 - High Frequency Noise - Waveform 3 Amplitude Determination.....	189
Figure 22.UG-9 - High Frequency Noise - Waveform 3 Amplitude Determination.....	190
Figure 22.UG-10 - High Frequency Noise - Waveform 4 Amplitude Determination.....	190
Figure 22.UG-11 - Ripple with HF Noise - Waveform 5A Amplitude Determination.....	191
Figure 22.UG-12 - Positive Inductive Kick Effect - Waveform 3 Amplitude Determination, Positive Polarity Applied.....	191
Figure 22.UG-13 - Negative Inductive Kick Effect	192

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 23

Lightning Direct Effects

**Based on
DO-160G Section 23**

TABLE OF CONTENTS

23.UG.0	Lightning Direct Effects.....	197
23.UG.1	Purpose of Tests.....	197
23.UG.2	Definitions.....	197
23.UG.3	Equipment Categories.....	201
23.UG.4	General Test Procedures.....	201
23.UG.4.1	High Voltage Strike Attachment Testing.....	202
23.UG.4.1.1	High Voltage Test Waveforms.....	202
23.UG.4.1.2	Initial Leader Attachment Test.....	202
23.UG.4.1.2.1	Test Purpose.....	202
23.UG.4.1.2.2	Test Object.....	202
23.UG.4.1.2.3	Test Fixture.....	202
23.UG.4.1.2.4	Test Setup.....	202
23.UG.4.1.2.5	Test Waveforms.....	203
23.UG.4.1.2.6	Measurements and Data Recording.....	203
23.UG.4.1.2.7	Test Procedure.....	203
23.UG.4.1.2.8	Data Interpretation.....	205
23.UG.4.1.3	Swept Channel Attachment Test.....	205
23.UG.4.1.3.1	Test Purpose.....	205
23.UG.4.1.3.2	Test Object.....	205
23.UG.4.1.3.3	Test Fixture.....	205
23.UG.4.1.3.4	Test Setup.....	206
23.UG.4.1.3.5	Test Waveforms.....	206
23.UG.4.1.3.6	Measurements and Data Recording.....	206
23.UG.4.1.3.7	Test Procedure.....	206
23.UG.4.1.3.8	Data Interpretation.....	206
23.UG.4.2	High Current Physical Damage Testing.....	206
23.UG.4.2.1	High Current Test Waveforms.....	206
23.UG.4.2.2	Arc Entry Test.....	213
23.UG.4.2.2.1	Test Purpose.....	213
23.UG.4.2.2.2	Test Object.....	214
23.UG.4.2.2.3	Test Fixture.....	214
23.UG.4.2.2.4	Test Setup.....	214
23.UG.4.2.2.5	Test Waveforms.....	214
23.UG.4.2.2.6	Measurements and Data Recording.....	214
23.UG.4.2.2.7	Test Procedure.....	215
23.UG.4.2.2.8	Data Interpretation.....	215
23.UG.4.3	Additional Test Requirements.....	215
23.UG.4.3.1	Externally Mounted Fuel Equipment.....	215
23.UG.4.3.2	Methods for Detection of Ignition Sources.....	215
23.UG.4.3.2.1	Photographic method.....	215

23.UG.4.3.2.1.1	TestPurpose.....	215
23.UG.4.3.2.1.2	Test Equipment.....	215
23.UG.4.3.2.1.3	Test Procedure.....	215
23.UG.4.3.2.1.4	Data Requirements.....	216
23.UG.4.3.2.2	Ignitable Mixture (Flammable Gas) Test Method	216
23.UG.4.3.2.2.1	Test Purpose.....	216
23.UG.4.3.2.2.2	Test Equipment.....	216
23.UG.4.3.2.2.3	Test Procedure.....	217
23.UG.4.3.2.2.4	Data Requirements.....	218
23.UG.4.3.3	Measurement of Induced Voltage in External Hardware.....	219
23.UG.4.3.3.1	Test Purpose.....	219
23.UG.4.3.3.2	Test Object.....	219
23.UG.4.3.3.3	Test Fixture.....	219
23.UG.4.3.3.4	Test Setup.....	219
23.UG.4.3.3.5	Measurement and Data Recording.....	219
23.UG.4.3.3.6	Test Procedure.....	219
23.UG.4.3.3.7	Data Interpretation.....	219

TABLE OF FIGURES

Figure 23.UG-1	- Example of a typical flashover.....	199
Figure 23.UG-2	- Example of a typical streamer.....	200
Figure 23.UG-3	- Positive Polarity with un-modified Electrode	205
Figure 23.UG-4	- Typical Component A Oscillatory Current Waveforms.....	208
Figure 23.UG-5	- Typical Component A Unipolar Current Waveforms	208
Figure 23.UG-6	- Typical Component A Action Integral.....	209
Figure 23.UG-7	- Typical Component B Current Waveform.....	209
Figure 23.UG-8	- Typical Component B Charge Transfer	210
Figure 23.UG-9	- Typical Component C Current Waveform	210
Figure 23.UG-10	- Typical Component C Charge Transfer	211
Figure 23.UG-11	- Typical Component D Oscillatory Current Waveforms	211
Figure 23.UG-12	- Typical Component D Unipolar Current Waveform.....	212
Figure 23.UG-13	- Typical Component D Action Integral.....	212
Figure 23.UG-14	- Typical Component C* Current Waveform	213
Figure 23.UG-15	- Typical Component C* Charge Transfer Waveform	213
Figure 23.UG-16	- Minimum Ignition Energy Curve.....	218
Figure 23.UG-17	- Voltage Waveform A	220
Figure 23.UG-18	- Voltage Waveform D	221
Figure 23.UG-19	- Test Electrode for Swept Channel Attachment Test	222
Figure 23.UG-20	- Typical Jet DivertingTest Electrodes	223

DO-160G

**Environmental Conditions and Test Procedures
for Airborne Equipment**

User Guide for Section 26

Fire, Flammability

**Based on
DO-160G Section 26**

TABLE OF CONTENTS

26.UG.4	Fire Proof/Resistance Test Procedure.....	229
26.UG.4.3	Flame Temperature.....	229
26.UG.6.2	Vertical Bunsen Burner Test for Cabin and Cargo Compartment Materials.....	230
26.UG.6.2.1.1	Ignition Time.....	230
26.UG.6.2.1.4	Burn Length.....	230
26.UG.6.2.2.1	Test Cabinet.....	231
26.UG.6.2.2.3	Burner.....	232
26.UG.6.2.2.3.3	Flame Height Indicator.....	232
26.UG.6.2.3.3	Specimen Size.....	232
26.UG.6.2.3.4	Specimen Thickness.....	232
26.UG.6.2.4	Conditioning.....	233
26.UG.6.2.6	Test Procedure.....	233
26.UG.6.3.1.1	Ignition Time.....	235
26.UG.6.3.2.1	Test Cabinet.....	235
26.UG.6.3.2.3	Burner.....	235
26.UG.6.3.2.6	Flame Height Indicator.....	235
26.UG.6.3.5.3	Specimen Size.....	236
26.UG.6.3.5.4	Specimen Thickness.....	236
26.UG.6.3.6	Conditioning.....	236
26.UG.6.3.7.1	Burner Adjustment.....	236
26.UG.6.4.1.1	Ignition Time.....	237
26.UG.6.4.2.1	Test Enclosure and Setup.....	237
26.UG.6.4.2.3	Burner.....	237
26.UG.6.4.2.3.1	Burner Fuel.....	238
26.UG.6.4.3.2	Specimen Length.....	238
26.UG.6.4.4	Conditioning.....	238
26.UG.6.5.1	Burner Adjustment.....	238
26.UG.6.5.2	Test Procedure.....	239

TABLE OF FIGURES

Figure 26.UG-1: Alternative Setup for 60-Degree Electrical Wire Bunsen Burner Test.....	239
---	-----

26.UG.6.4.6 Report**26.UG.6.4.6.1 Material Identification****26.UG.6.4.6.2 Test Results****26.UG.6.4.7 Requirements****26.UG.6.4.7.1 Extinguishing Time****26.UG.6.4.7.2 Drip Extinguishing Time****26.UG.6.4.7.3 Burn Length****26.UG.6.4.7.4 Wire Breakage**

APPENDIX A - MEMBERSHIP

RTCA Special Committee 135 Environmental Testing

Chairman		Organization
Brad	Green	Honeywell International, Inc.
Designated Federal Official		Organization
Lee	Nguyen	Federal Aviation Administration
RTCA Program Director		Organization
Sophie	Bousquet	RTCA, Inc.
Hal	Moses	RTCA, Inc.
Members		Organization
David	Akers	GE Aviation
Cathy	Au	UK CAA
Bernard	Badonnel	Thales
Joshua	Bakk	Rockwell Collins, Inc.
Doug	Ballard	L-3 Communications
Joachim	Bargmann	Airbus
Susan	Beard	Rockwell Collins, Inc.
Jean-Marc	Benoit	Bombardier Aerospace
Endre	Berecz	L-3 Communications
Remi	Berge	Intespace
Massimiliano	Bertoldi	CELAB SRL
Christian	Bertran	Airbus
Chuck	Beuning	Cessna Aircraft Company
Rick	Bewsey	UK CAA
Julien	Blanc	Thales
Erik	Borgstrom	Environ Laboratories, LLC
Dean	Boston	Genesys Aerosystems
Nadia	Bouhalli	Airbus
Joe	Bowers	American Airlines, Inc.
Patricia	Cahill	Federal Aviation Administration
Jean	Cartier	Transport Canada
Ken	Cechura	Rockwell Collins, Inc.
Hing	Chan	Pratt & Whitney Canada
Jean-Paul	Chaussonnet	Airbus
Philippe	Chenebault	Dassault Aviation
Ian	Chrimes	UK CAA

Philippe	Clermont	Gerac
Matthieu	Cognet	Emitech
Jonathan	Coke	Gables Engineering, Inc.
Richard	Collum	Goodrich
Bernard	Colomies	SOPEMEA
Ernie	Condon	National Institute for Aviation Research (NIAR) at Wichita State University
Nick	Conquest	National Institute for Aviation Research (NIAR) at Wichita State University
Steve	Cook	DNB Engineering
John	Covell	United Technologies Corporation
Gilles	Crousier	TURBOMECA
Elysabeth	Cummings	Rosen Aviation
Marco	Da Silva	Bombardier Aerospace
Steven	Davidson	UTC Aerospace Systems
Alex	Davis	GE Aviation
Alexia	Delnevo	Airbus
Didier	DEMATA	Liebherr
Sal	Detruit	Element Materials Technology
Richard	Devy	Thales
Roger	Dieterich, Jr.	Universal Avionics Systems Corp.
William	Donoghue	Pratt & Whitney United Technologies
Cecile	Dorgan	DGA/DT/ST/IP/ASA (Ministere De La Defence-France)
Michael	Dosch	The Boeing Company
Soizic	Dubois	Gerac
Brant	Duke	Pratt & Whitney Canada
Robert	Erlandson	NISC III
Richard	Errhalt	U.S. Army
Mike	Falzone	Garmin Ltd.
Marcelo Tadeu	Ferreira	EMBRAER
Vic	Fisher	Smiths Aerospace
Tim	Fletcher	Bell Helicopter Textron, Inc
Franck	Flourens	Airbus
Patrice	Foutrel	Sagem Avionics, Inc.
Robert	Frazier	Federal Aviation Administration
Judith	Gallman	Gulfstream Aerospace Corporation
Jeff	Gardlin	Federal Aviation Administration
Bill	Gatheridge	Yokogawa Corporation of America
Rick	Gaynor	Retlif Testing Laboratories
Joe	Gerke	Dassault Falcon Jet Corporation
Dara	Gibson	Federal Aviation Administration
Patrick	Hall	Elite Electronic Engineering Inc.
Jim	Hatlestad	The Boeing Company
Terri	He	The Boeing Company
Stoefen	Henning	Airbus

Paul	Hernandez	U.S. Army
Eric	Hiner	DME Corporation
Daniel	Hinton	U.S. Army
Robert	Hoeckele	UTC Aerospace Systems
Vsevolod	Ivanov	Parker Hannifin - Aerospace, Control Systems
David	Jennings	Rockwell Collins, Inc.
Michael	Jennings	National Institute for Aviation Research (NIAR) at Wichita State University
Paul	Jonas	National Institute for Aviation Research (NIAR) at Wichita State University
Don	Jones	CKC Laboratories
Julian	Jones	Hursley EMC Services
Howard	Jordan	Hawker Beechcraft Corporation
JinPyong	Jung	Korea Aerospace Research Institute
Ludovic	Kaman	Rockwell Collins, Inc.
Kamiar	Karimi	The Boeing Company
David	Kerr	Garmin Ltd.
Tehmosp	Khan	Universal Avionics Systems Corp.
Ron	Koepp	National Institute for Aviation Research (NIAR) at Wichita State University
Wolfgang	Kuerner	Airbus
Ahmet Hakan	Kumbasar	STM A.S
Marvin	Kumley	Garmin Ltd.
Jean-Christophe	Lamy	European Aviation Safety Agency (EASA)
Arnaud	Ledreux	Aeroconseil
Dominique	Lemaire	Airbus
Benoit	Lepinard	Aeroconseil
Philippe	Leroux	Sagem
George	Ligler	Project Management Enterprises Inc.
Tim	Lusha	DLS Electronic Systems, Inc.
James	Lyll	Embry-Riddle Aeronautical University
Donald	MacDonald	Gables Engineering, Inc.
Michael	Maritan	Esterline CMC Electronics
John	Markham	Cobham Aerospace Communications
Joe	Marotta	Honeywell International, Inc.
Billy	Martin	National Institute for Aviation Research (NIAR) at Wichita State University
Evelyn	Matheson	The Boeing Company
Jerome	Mavier	Airbus
Bryan	McCoy	Rockwell Collins, Inc.
Kyle	McMullen	National Institute for Aviation Research (NIAR) at Wichita State University
Abner	Merriweather	U.S. Army

Michael	Mertens	Barco Orthogon
Al	Meyer	Rockwell Collins, Inc.
James	Mills	TUV SUD America, Inc.
Jean-Patrick	Moreau	Dassault Aviation
Jim	Morris	TUV SUD America, Inc.
Mel	Nance	Moog, Inc.
Dong	Nguyen	U.S. Army
Tu	Nguyen	U.S. Army
Edward P	Nixon	Gulfstream Aerospace Corporation
Keith	Peavler	Honeywell International, Inc.
Jeff	Phillips	Cessna Aircraft Company
Mike	Pomeroy	National Technical Systems
Marc	Poncon	Eurocopter
Doug	Pope	Honeywell International, Inc.
Jack	Prawica	DLS Electronic Systems, Inc.
James	Press	DNB Engineering
Eric	Qian	Aviage Systems
Mario	Rinaldi	Hamilton Sundstrand
Ricardo	Robles	Gables Engineering, Inc.
Bernd	Roth	LBA Germany
Philippe	Sant-Anna	Airbus
Joseph	Scavo	Woodward MCP
Paul	Schwerman	Honeywell International, Inc.
Paul	Scott	Electronics Test Centre
Alistair	Scott	BAE Systems
Rod	Setter	Honeywell International, Inc.
Harlan	Sharpe	National Institute for Aviation Research (NIAR) at Wichita State University
Gary	Smith	Honeywell International, Inc.
Rob	Spencer	Smiths Aerospace
Tim	Steinbach	Rockwell Collins, Inc.
Erik	Stevens	ERA
Henning	Stoefen	Airbus
Bryan	Stratton	Intertek Testing Services NA
Ayman	Surial	Bombardier Aerospace
Christophe	Taurand	Thales Avionics
Brandi	Teel	RTCA, Inc.
John	Tepper	Federal Aviation Administration
Alan	Thompson	Environ Laboratories, LLC
Ken	Thompson	U.S. Army
Jerome	Toulouse	Rockwell Collins, Inc.
Robert	Tozier	CKC Laboratories
Luke	Turnbull	CONEKT
Steve	Uhrich	The Boeing Company

Jacob	VanDyke	Honeywell International, Inc.
Merrill	Vaughan	The Boeing Company
Jeffrey	Viel	National Technical Systems
Anna	Von Groote	EUROCAE
Matthew	Wade	Federal Aviation Administration
David	Walen	Federal Aviation Administration
Derek	Walton	LF Research
Kenneth	Webb	Rockwell Collins, Inc.
Hakan	Wernstrom	SAAB
Frank	White	Garmin Ltd.
Matthew	Wills	National Institute for Aviation Research (NIAR) at Wichita State University
Karl	Yaeger	Pratt & Whitney United Technologies
Khan	Zaman	TRW
Dan	Zanette	Electronics Test Centre
Lidong	Zhou	GE AVIC Civil Avionics Systems Co. Ltd.
David	Zimmerman	Spectrum EMC Consulting, LLC
Edouard	Zundel	Aeroconsel